

BROODING FROG POLYRESIN BIRD BATH WNC-796


Read the assembly instructions carefully and follow the care instructions. Keep this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.

Select a flat, level surface to place the birdbath.



| No. | PART | QTY. |
|-----|----------|------|
| A | Bowl | 1 |
| B | Pedestal | 1 |



ASSEMBLY

1. Align Bowl (A) with Pedestal (B) and twist the bowl to lock the parts together.
2. Fill the bowl with clean water, approximately 1/2 gallon. Avoid heavily chlorinated water as it may damage the finish.

CHOOSING A LOCATION

Select a smooth, level surface to place the bird bath.

A large stepping stone or paving stone (not included) is recommended to help ensure the bird bath remains evenly balanced.

CLEANING

Cleaning the birdbath 1-2 times per week is recommended.

 **HAND-WASH ONLY**  **DO NOT USE BLEACH**

1. Empty the old water.
2. Wash the bowl with clean water and a soft cloth.
3. Thoroughly rinse the bowl with clean water, never use a high-pressure sprayer as doing so may damage the finish.

Over time, the finish may gradually mellow in color; this is part of the natural aging process and not cause for return.

NOTE: Bird claws are sharp and may damage the finish inside the bowl. Consider applying a suitable, non-toxic sealant to protect the finish; consult a professional at your local hardware store and carefully follow manufacturer instructions.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE USE OF PROTECTIVE COATINGS.

SAFETY STATEMENTS & WARNINGS

- Do not install on uneven surfaces as this could cause it to tip over.
- Do not use harsh chemicals, abrasive materials, or a pressure washer to clean this unit.
- During freezing weather, empty the birdbath and store it indoors; allowing ice to form in the bowl may cause it to crack or break.

Any modification to the product or failure to follow recommended care will void the product warranty.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.