


BRAZILIAN HAMMOCK WITH STAND

Read all assembly and care instructions carefully before using this product. Save these instructions for future reference.








Select a smooth, level surface to place the hammock stand.

Assemble components on a soft, clean surface to avoid scratching/damaging the finish.



400 pounds
181.4 kg
Weight Capacity

WARNING: Failure to read and follow instructions and safety warnings could result in serious injury or damage to property.

No.	PARTS	QTY.
A	 Upright Tube (L/R)	2
B	 Crossbar	1
C	 Leg	2
D	 Hook Bolt Set	2
E	 Threaded Knob	5
F	 Carrying Case	1
G	 Brazilian Hammock	1



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

WARNING

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children away during assembly.

CAUTION

This hammock and stand are not designed for use as a swing. Bouncing, swinging, or any other significant movement while in use may result in serious injury.

This stand must be used on a level, stable surface. Make sure all hardware and connection points are securely tightened before every use.

ASSEMBLY

! Carefully read all assembly steps, care instructions, and safety information before using this product. **!**

Save these instructions for future reference.

Assemble components on a soft, clean surface to avoid scratching/damaging the finish.

When choosing a location for your hammock stand, select a smooth, level surface.

Do not install on dangerous terrain or objects such as slopes, on rocks, or in bodies of water.

STEP 1

B: 1 C: 2 E: 3

- Install one Threaded Knob (E) into the center of Crossbar (B).
- Slide two Legs (C) into Crossbar (B).
- Align the mounting holes and securely fasten each leg to the crossbar using one Threaded Knob (E).

NOTE: Installation of the threaded knob into the center of the crossbar is essential for achieving the maximum weight capacity. If the knob is not installed, the crossbar could bend and break the stand.

STEP 2

A: 2 E: 2




- Slide to Upright Tube (A) onto the legs.
- Align the mounting holes and securely fasten each upright tube using Threaded Knobs (E).

STEP 3

D: 2



- Ensuring the hook faces downward, securely install one Hook Bolt Set (D) on the outside of each upright, as shown.

IMPORTANT: The illustration is for reference only. Installation of the hooks will vary by hammock size. Adjust hooks as needed.



HANGING YOUR HAMMOCK

⚠ IMPORTANT: Always leave some slack in the fabric when hanging your hammock. The center of the hammock should be at a height where the user can enter and exit the hammock safely.



Lay the ropes of your Brazilian hammock over the top of the uprights and affix the rings to the hooks.

The hammock should have a slight curve when first hung. There should be enough slack to enter and exit the hammock safely, but it must also be tight enough to accommodate the user's weight.

The fabric and ropes stretch over time; adjust the hooks as needed.

HOW TO RELAX IN YOUR HAMMOCK

⚠ WARNING: Failure to read and follow instructions and safety warnings could result in serious injury.

⚠ BEFORE USE: Carefully read all use, care, and safety information to ensure this product is used safely.



Take your time getting into and out of your hammock; any hammock can tip when weight is not centered.



1 Separate the sides of the hammock and locate the center of the hammock.

Products shown are for demonstration purposes only.



2 With your feet flat on the ground, firmly hold both sides, then pull the back side up behind your shoulder while slowly lowering yourself into a seated position.

Products shown are for demonstration purposes only.



3 Carefully lift your legs into the hammock and slowly pivot your body into a comfortable position. Slowly and carefully reposition as needed.

If the hammock begins to tip, position your feet back on the ground and start again.

Products shown are for demonstration purposes only.



4 To exit the hammock, firmly hold both sides of the hammock, swing your feet out and place them flat on the ground. Grip the edge of the hammock and slowly stand up.

Products shown are for demonstration purposes only.

GENERAL USE & CARE



WARNING: Do not use if parts are missing, worn, or damaged.



WARNING: Never leave a hammock hanging when not in use.



WARNING: Do not allow children to use this product without constant adult supervision.



WARNING: Always keep weight centered when entering and exiting the hammock.

SAFE USE: Follow all safety statements and warnings (page 5).

Never exceed the weight capacity of the hammock stand, 400 lbs.

Take your time getting in and out of the hammock. Any hammock may tip if your weight is not centered.

Swinging, bouncing, jumping, or any other excessive movement may result in serious injury, including, but not limited to, the stand tipping over or components disconnecting.

CHILDREN: This product is only to be used by adults and person(s) with developed motor skills who also understand the potential dangers if misused. Supervise children at all times. Never allow small or young children to enter or exit a hammock without adult assistance. Never allow or encourage children to sleep or play in a hammock. Always teach and practice safe hammock use, with and without a hammock stand. Always teach and practice safe hammock use.

SUN EXPOSURE: All fabrics will eventually fade and degrade from sun exposure. The less direct sunlight the hammock is exposed to, the longer the life of fabric and ropes will be.

INSPECTION: Frequently check hardware to ensure it remains securely fastened; tighten loose hardware as needed. Do not use the stand if parts are missing, broken, damaged, or worn. Always inspect the hammock before every use; do not use if fabric is torn or ropes are frayed.

STORAGE: Store indoors when not in use. Cool, dry locations are recommended to prevent damage that may result from exposure to moisture. If the stand is outdoors after use, cover it to prevent damages caused by water and sunlight.

SCRATCHES: The powder coating on the stand is tough and durable, but even under normal use, some scratching is inevitable. To prevent excessive rust, wipe scratched areas to remove moisture.

CLEANING

 DO NOT USE BLEACH OR FABRIC SOFTENERS

 DO NOT IRON HAMMOCK

 DO NOT TUMBLE DRY

 LAY HAMMOCK FLAT TO DRY

HAMMOCK

Hand-wash with warm water, soap or mild detergent, and a soft-bristled scrub brush. Rinse thoroughly, ensuring all soap residue has been removed. Air-dry only, laying the hammock on a flat surface to prevent the ropes from stretching.

Machine wash on the gentle/delicate cycle, using a mesh net laundry washing bag and mild detergent. Before placing your hammock in the laundry washing bag, tie the ends of the hammock together to prevent tangling. Air-dry only, laying the hammock on a flat surface to prevent the ropes from stretching.

Never fold the hammock when wet or store it in a damp place as doing so will promote mold and mildew growth.

HAMMOCK STAND

Use a soft cloth and warm water to wipe down the stand. Wipe away moisture with a soft, clean cloth.

! SAFETY STATEMENTS & WARNINGS !

This hammock and stand are only to be used by adults and person(s) with developed motor skills who understand the potential dangers if they are misused.

Supervise children at all times. Never allow small or young children to enter or exit a hammock without adult assistance. Never allow or encourage children to sleep or play in a hammock. Always teach and practice safe hammock use.



Take your time getting into and out of your hammock; any hammock can tip when weight is not centered.

To prolong the lifespan of your Sunnydaze hammock, we recommend that you always bring the hammock inside when not in use, as the sun, rain, and other outdoor elements will deteriorate the materials over time. If using near bodies of salt water, it is important to rinse the hammock regularly. In addition, ensure the hammock is dry when storing to prevent mold and mildew.



WARNING: Do not use if parts are missing, worn, or damaged.



WARNING: Never leave a hammock hanging when not in use.



WARNING: Do not allow children to use this product without constant adult supervision.



WARNING: Always keep weight centered when entering and exiting the hammock.

- **DO NOT** exceed the recommended weight capacity.
- **DO NOT** enter the hammock feet first.
- **DO NOT** dive into or jump in the hammock.
- **DO NOT** stick your head or any other body part through the ropes.
- **DO NOT** pull yourself up or reposition yourself by the ropes.
- Keep hanging ropes as straight as possible, do not twist or knot. Never untie the ropes.
- **Hammocks are not designed for swinging.** Excessive swinging and other rough play may result in injuries and will wear out your hammock and stand prematurely.
- **DO NOT** leave children unattended in hammocks or near hammocks.
- Pets should not be allowed into hammocks as it may result in injuries or damage to the product.
- Hammock fabrics and accessories will become worn over time and use, do not use the hammock if fabric is torn, or ropes are frayed.
- If possible, use this product over a surface with shock-absorbing properties such as carpet or grass. Doing so helps minimize the risk of injury if occupant(s) fall out of the hammock.
- **ALWAYS** store the hammock indoors when not in use. Cover or store the stand when not in use.
- **DO NOT** leave the hammock on the stand when not in use. Uplift from wind will cause stand to tip over and may damage the hammock and the stand.



LEARN MORE ABOUT HAMMOCK SAFETY!

SCAN THE CODE WITH YOUR SMARTPHONE

OR VISIT

<https://tiny.cc/hammock-safety>

TROUBLESHOOTING

If you are unfamiliar with using a hammock, it can leave you feeling uneasy; take some time to get used to it. Always enter and exit your hammock slowly. Swinging or aggressive movement can easily make the hammock or stand tip over and/or cause the metal to bend.

THE STAND SEEMS UNSTABLE

- Ensure all components are assembled correctly and the threaded knobs are fully engaged within the mounting holes. It is essential that all threaded knobs are installed.
- Check to ensure the hooks are securely fastened.
- Make sure the stand is on a flat, level surface.
- Due to the portable design of the stand, there will always be some 'give' at the assembly points; this is normal. Ensure occupant(s) are entering the hammock safely. Entering the hammock and adjusting position slowly is necessary for safe use of this product.

MY HAMMOCK HANGS TOO LOW TO THE GROUND OR IS TOO HIGH TO ENTER SAFELY

- Adjust the placement of the hooks; the higher the hook, the lower the hammock will hang.
- Always leave some slack in the hammock fabric.

I HAVE OTHER QUESTIONS OR CONCERNS

Contact Sunnydaze Decor customer service team directly through one of the methods mentioned at the top of page 1. To expedite response time, please have the item number and order information available.

Any modification to the product or failure to follow recommended care will void the product warranty.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.